



ification Summary

O2-A1	O2-A2	O2-A3	O2-C2	O2-G1	O2-G2
200 to 240	80 to 120	60 to 85	80 to 120	65 to 85	30 to 42
< 15	< 15	< 15	< 50	< 18	< 20
< 2.5	< 2.5	< 2.5	< 2.5	< 2.5	< 2.5
> 12	> 24	> 36	> 24	> 12	> 24
-30 to 55	-30 to 55	-30 to 55	-30 to 55	-30 to 55	-30 to 55
80 to 120	80 to 120	80 to 120	80 to 120	80 to 120	80 to 120
5 to 95	5 to 95	5 to 95	5 to 95	5 to 95	5 to 95
47 to 100	47 to 100	47 to 100	47 to 100	47 to 100	47 to 100

ent environments unless otherwise stated. As applications of use are outside our control, the responsibility. Customers should test under their own conditions, to ensure that the sensors

Alphasense sensors. Soldering, gluing or other methods of connection will void your